
## **POWER CONNECTOR - WIRING DIAGRAM**

## EXTERNAL POWER - M8 3-PIN MALE

Connector Pin #	Signal	Pin Assignment	
1	5-28VDC (+)	Front	Back
3	No Connection	3 1	
4	Negative (-)		





Installation tool for wire termination (included in field attachable connector packaging)





IMPORTANT NOTE: ensure that you have properly wired the connection to avoid permanent electrical damage to the Wavelet device.



## For technical support please contact: support@ayyeka.com

+1 (310) 876-8040 Ext. 3 (US)

+31 (40) 209-1001 Ext. 3 (EMEA)

